



Pump Model - version

JETCOM 102 M - N.3.- -

Attention: check the correspondence with the serial number of the pump.

Company Name
Contact
Telephone
FAX
E-Mail address

Receiver

From

JETCOM 102 M - N.3.- - @ 102670040_a

JETCOM 102 M @ 102670040

| Item | Quant | Item no. | Description | Unit pr. |
|------|-------|-----------|-----------------------|----------|
| 1 | 1 | R00005106 | PUMP BODY | On req. |
| 13 | 1 | R00004650 | FAN GUARD | On req. |
| 12 | 1 | R00005107 | FAN | On req. |
| 3 | 1 | R00005178 | SUPPORT | On req. |
| 7 | 1 | R00005151 | MOTOR SHAFT | On req. |
| 28 | 1 | R00004187 | OR | On req. |
| 45 | 1 | R00005110 | NUTS AND BOLTS | On req. |
| 19 | 1 | R00005111 | FRONT BEARING | On req. |
| 20 | 1 | R00005112 | REAR BEARING | On req. |
| 23 | 1 | R00005113 | CAPACITOR | On req. |
| 4 | 1 | R00005153 | IMPELLER | On req. |
| 11 | 1 | R00005115 | MOTOR COVER | On req. |
| 10 | 1 | R00005116 | MOTOR | On req. |
| 6 | 1 | R00004028 | DIFFUSER ASSEMBLY | On req. |
| 16 | 1 | R00008145 | SEAL | On req. |
| 14 | 1 | R00004811 | TERMINAL BOARD | On req. |
| 36 | 1 | R00004016 | MECHANICAL SEAL COVER | On req. |
| 25 | 1 | R00004017 | LOAD PLUG | On req. |
| 26 | 1 | R00004018 | DISCHARGE PLUG | On req. |

