

User Manual

2HP Bench-Mounted Belt Grinder with

NVR Switch (1,220 x 50mm Belt)

812146 - ATL1500/482



Protect yourself and others by observing all safety information, warnings and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property.

Please retain instructions for future reference!

1. Introduction

Dear Customer,

Thank you for purchasing this Abbott & Ashby product, which has passed through our extensive quality assurance process. Every care has been taken to ensure that it reaches you in perfect condition.

2. Key Features

POWERFUL 2HP MOTOR

Delivers more torque for effortless material removal and superior performance.

RUNS COOLER

Improved sealed cooling system keeps operating temperatures lower, reducing wear and tear.

ENHANCED DURABILITY

High-tensile cast aluminum base and body provide superior strength while maintaining a lighter weight. Rubber antivibration feet stabilise the unit to your bench or pedestal.

NVR & E-STOP SWITCH

Ensures safety by cutting power entirely during outages and preventing accidental restarts.

MORE POWER FOR BIG JOBS, LESS WEAR FOR EVERYDAY USE

Ideal for professional and industrial applications.

FACTORY FITTED AA482 LINISHER

- Patent pending design allows for fast changes to the working angle without disassembly in 6° increments.
- Top platen can be used for flat surface grinding and can be moved out of the way for convenient free strapping.
- Easy belt tracking adjustment knob and lock.
- Fast belt changes with patent pending self-locking push in push out arm.

3. Contents

1. Introduction	2
2. Key Features	2
3. Contents	3
4. Technical Specifications	4
5. ISO 7010 Symbols used in this manual	4
6. Warnings	5
7. Standards and Approvals	7
8. Cautions	8
9. Product Pieces	9
10. Operation	11
11. Warranties – Terms and Conditions	13

4. Technical Specifications

Abbott & Ashby ATL1500/482	
Part No	ATL1500/482
Item Code	812146
Input/Output	1700W/1500W - 2HP
Amps	5.2
Volts	240V - 50Hz (1 Ph)
RPM	2850
Belt	1,220 x 50mm (48 x 2") – 240 Grit
Disc	178mm (7") diameter – 120 Grit
Contact Wheel	89mm (3 ½")
Length	238mm
Width	435mm
Height	601mm
Weight	24kg
Barcode	9312198867602

5. ISO 7010 Symbols used in this manual	
4	Warning - Electrical safety
	Warning – Potential consequences of use outside of intended application(s). Includes environmental condition warnings.
	Mandatory warning
	Warning to disconnect power
	Read carefully

6. Warnings		
	Read the manual carefully before starting and retain for future reference. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term "power tool" in all of the warnings listed below refers to your mains-operated (corded) power tool.	
	Prior to starting installation or maintenance the product must be disconnected from the power supply.	
4	Always wear eye protection.	
Â	 ELECTRICAL SAFETY a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock. b. Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded. c. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock. d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock. e. When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock. 	
	 WORK AREA a. Keep work area clean and well lit. Cluttered and dark areas invite accidents. b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes. c. Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control. d. For maximum safety, always secure the machine to a stable, level workbench before use. Proper mounting ensures optimal control of the workpiece and helps minimise movement and noise during operation. PERSONAL SAFETY 	
	 a. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while 	

<u>г</u>	
	operating power tools may result in serious personal injury.
	b. Use safety equipment. Always wear eye protection. Safety
	equipment such as dust mask, non-skid safety shoes,
	hard hat, or hearing protection used for appropriate
	conditions will reduce personal injuries.
	c. Avoid accidental starting. Ensure the switch is in the off-
	position before plugging in. Carrying power tools with your
	finger on the switch or plugging in power tools that have
	the switch on invites accidents. d. Remove any adjusting key or wrench before turning the
	power tool on. A wrench or a key left attached to a
	rotating part of the power tool may result in personal
	injury.
	e. Do not overreach. Keep proper footing and balance at all
_ •	times. This enables better control of the power tool in
	unexpected situations.
	f. Dress properly. Do not wear loose clothing or jewellery.
	Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught
	in moving parts.
	g. If devices are provided for the connection of dust
	extraction and collection facilities, ensure these are
	connected and properly used. Use of these devices can
	reduce dust-related hazards.
	POWER TOOL USE AND CARE
	a. Do not force the power tool. Use the correct power tool for
	your application. The correct power tool will do the job better and safer at the rate for which it was designed.
	b. Do not use the power tool if the switch does not turn it on
	and off. Any power tool that cannot be controlled with the
	switch is dangerous and must be repaired.
	c. Disconnect the plug from the power source before making
	any adjustments, changing accessories, or storing power
	tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
	d. Store idle power tools out of the reach of children and do
	not allow persons unfamiliar with the power tool or these
	instructions to operate the power tool. Power tools are
	dangerous in the hands of untrained users.
	e. Maintain power tools. Check for misalignment or binding
	of moving parts, breakage of parts and any other
	condition that may affect the power tools operation. If
	damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
	f. Keep cutting tools sharp and clean. Properly maintained
	cutting tools with sharp cutting edges are less likely to
	bind and are easier to control.
	g. Use the power tool, accessories and tool bits etc., in
	accordance with these instructions and in the manner
	intended for the particular type of power tool, taking into
	account the working conditions and the work to be
1	
	performed. Use of the power tool for operations different from intended could result in a hazardous situation.

^	SERVICE
<u>.</u>	a. Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

4	Any changes or modification to the wiring must be carried out by suitably qualified personnel.
Â	A qualified electrician should correctly size and install residual current devices to protect the power supply. The fitment of additional surge protection is recommended.
	This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
4	Do not use bench machinery in areas where there is a risk of explosion or fire from combustible materials, flammable liquids, paint, varnish, petrol etc. flammable gases and dust of an explosive nature. As a precaution it is recommended that you consult an expert on a suitable fire extinguisher and its use. The metal particles (sparks) which are produced during grinding are hot and could ignite any combustible material in the vicinity of the operation.
	Ensure that the installation will comply with all applicable local regulations.

7. Standards and Approvals


	CTick – ACN002 123 337
Patent Pending	2020902087

8. Cautions


- Ensure that power tools are disconnected from the mains supply when not in use, before servicing, lubricating or making adjustments and when changing accessories such as belts.
- Always use the correct type of belt and disc for the type of operation to be carried out and the material being machined.
- Only use abrasives that are in good condition. This will improve grinding and reduce the load on the machine ensuring a longer life of the belt, disc and the machine.
- Never use damaged components or accessories. This could cause injury to the operator and bystanders and damage to the machine.
- Do not use belts that are larger than specified, only use accessories that are rated for the machine.
- Do not attempt to modify the machine or its accessories in any way.
- Do not use excessive force on the linishing belt. Only use gradual pressure as this will reduce the wear on the machine and belt and increase its efficiency and operating life.
- Use approved safety glasses or goggles, face mask and if being used for an extended period wear ear defenders.
- Do not start the machine with the work piece in contact with the belt or sanding disc.
- Keep guards in place and in good working order. With the machine disconnected from the mains supply check that the guards are secure and fitted correctly.
- Do not attempt to grind objects that are too small to hold safely.
- Do not use the work piece to slow down the belt once the machine has been switched off.

9. Product Components

LINISHING ATTACHMENT (AA482)



(A) Main bracket
(B) Linishing belt
(C) Abrasive disc
(D) Backing plate
(E) 6 x Fasteners for backing plate
(F) Linishing guard
(G) 3 x cap screws for guard
(H) Drive pulley
(I) 3 x 6 x 20mm fasteners for main bracket
(J) 16mm nut
(K) Washer





Install the guard (F) over the assembly and tighten the 3 x cap screw (G).





Attach the abrasive disc (C) to the backing plate. Hold firmly for a few seconds to ensure the adhesive activates.





Push against the contact wheel towards the drive pulley to retract the extension arm and place the linishing belt (B) over the main wheel and the contact wheel. Refer to the inside of the belt for the correct installation direction of the belt.

Initially, there may be a tightness in the mechanism. This is normal and will improve with use.

Push against the contact wheel again to extend the extension arm. Ensure the belt is taut and not loose.

Once the belt is on the linisher, you can also push down on the bottom of the belt (B) to retract or extend the extension arm.

10. Operation



CAUTION Always ensure that the machine is switched off and plug is removed from the power point before making any adjustments.


BENCH MOUNTING

The machine should always be securely fastened to a workbench or pedestal stand before use. Proper mounting improves stability, enhances control of the workpiece, and helps reduce movement, noise, and vibration during operation. To mount, locate the mounting holes in the base. The length of the bolts or screws will depend on the thickness of the work surface. Where a steel bench is used, it is best to mount the machine onto a board first, then attach the board to the bench. This will further assist in reducing vibration. The machine is designed for fixed-position use in a workshop environment and must not be exposed to the elements.

SWITCHING ON AND OFF

Before connecting to the power supply rotate the wheel by hand to ensure that it is running free from obstruction. Connect to the mains supply and press the clasp in to release switch cover. Press the ON button (I) to start the machine.

This machine features an No Volt Release (NVR) Emergency stop (E-Stop) switch. To stop the machine, simply press the OFF button (O), or close the switch cover. The NVR switch ensures that the machine will not start again until the ON button is pressed.



LINISHER TRACKING

Turn the unit on and inspect the movement of the belt. If adjustments are required, move the lever into the loose position (A). To correct any tracking concerns, simply turn the knob (B) to adjust the tracking. Once adjusted, lock the lever gently back into place (C).



LINISHER WORKING ANGLE ADJUSTMENT


Loosen the bolt (A) out of the locking position and lift latch (B) to disengage the locking teeth (C); rotate the linisher to the desired angle. Lock the latch back into place firmly into the locking teeth and fasten the bolt to secure the linisher into position.



LINISHER GUARD

Designed for user ease when changing belts or servicing the unit. No need to remove other components in order to remove the guard. Loosen 3 x cap screw (A), rotate the guard slightly and remove.

LINISHER PLATEN



Platen swivels from under the belt at the top of the linishing attachment (1) to the bottom of the linisher (2).

Turn the lever (A) anti-clockwise to loosen the platen, and it can be moved into the desired location and locked back into place by tightening the lever (by rotating it clockwise). If required, you can lift the lever out of its seat to reset the lever turning position.

GENERAL INSPECTION

Regularly check that all the fixing screws are tight. They may vibrate loose over time.

11. Warranties – Terms and Conditions

Abbott & Ashby 2HP Bench-Mounted Belt Grinder with NVR Switch ATL1500/482 has a 3 Year Limited Product Warranty on motor, electrical switch, device body and guards but not including motor start / run capacitor and provided abrasive belt and disc.

This warranty is given in addition to the consumer guarantees found within the Australian Competition and Consumer Act 2010 (Cth) for goods purchased in Australia and the Consumer Guarantees Act 1993 NZ for goods purchased in New Zealand:

Honth & Astig Year Nth

This warranty will not apply:

- i. Where this product has been subjected to misuse, abuse, accident or want of care;
- ii. Where this product has been used for a purpose for which it was not designed or is not suited;

iii. Where the service of this product has been undertaken by a non-authorised person or company or if non-approved parts have been used;

iv. Where this product has been used for industrial purposes.

WARRANTY EXCLUSIONS

Wear parts or service-related parts required when performing normal and regular maintenance of this product are not covered by warranty unless it is found to be defective by an Authorised Service Centre. These include, but are not limited to: Belts and Disc, Contact Wheel, Motor Start / Run Capacitor.

1) White International Pty Ltd / White International NZ Ltd (White International) warrant that all products distributed are free from defects in workmanship and materials, for their provided warranty period as indicated on the top or opposite side of this document. Subject to the conditions of the warranty, White International will repair any defective products free of charge at the premises of our authorised service agents throughout Australia and New Zealand if a defect in the product appears during the warranty period. If you believe that you have purchased a defective product and wish to make a claim under this warranty, contact us on our Sales Hotline on 1300 783 601, or send your claim to our postal address or fax line below and we will advise you as to how next to proceed. You will be required to supply a copy of your proof of purchase to make a claim under this warranty.

2) This warranty excludes transportation costs to and from White International or its appointed service agents and excludes defects due to non-compliance with installation instructions, neglect or misuse, inadequate protection against the elements, low voltage or use or operation for purposes other than those for which they were designed. For further information regarding the suitability of your intended application contact us on our Sales Hotline on 1300 783 601. If you make an invalid claim under this warranty, the original product will be sent back to you unrepaired.

3) This warranty refers only to products sold after the 1st January 2012, and is not transferable to another product type and only applies to the original owner, purchaser or end user, and is in addition to the consumer guarantees found within the Competition and Consumer Act 2010 (Cth) for goods purchased in Australia and the Consumer Guarantees Act 1993 (NZ) for goods purchased in New Zealand.

4) Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

5) To the fullest extent permitted by law, White International excludes its liability for all other conditions or warranties which would or might otherwise be implied at law. To the fullest extent permitted by law, White International's liability under this warranty and any other conditions, guarantees or warranties at law that cannot be excluded, including those in the Competition and Consumer Act 2010 (Cth), is expressly limited to: (a) in the case of products, the replacement of the product or the supply of equivalent product, the payment of the cost of replacing the product or of acquiring an equivalent product or the repair of the product or payment of the cost of having the product repaired, is at the discretion of White International or a 3rd party tribunal elected under the Competition and Consumer Act 2010 (Cth) for goods purchased in Australia and the Consumer Guarantees Act 1993 (NZ) for goods purchased in New Zealand; and

6) To the fullest extent permitted by law, this warranty supersedes all other warranties attached to the product or its packaging.

7) In the case of services, supplying the services again or the payment of the cost of having the services supplied again, is at the discretion of White International or a 3rd party tribunal elected under the Competition and Consumer Act 2010 (Cth) for goods purchased in Australia and the Consumer Guarantees Act 1993 (NZ) for goods purchased in New Zealand.

8) Our warranty commences from the date of purchase of the above mentioned machine. Proof of purchase is required before consideration under warranty is given.

Record your date of purchase in the space below and retain this copy for your records.

Date of Purchase	Model Purchased
------------------	-----------------

https://abbottandashby.com.au/



www.whiteint.com.au www.whiteint.co.nz

Please always refer to our website for further technical information & new product innovations

Disclaimer: Every effort has been made to publish the correct information in this manual. No responsibility will be taken for errors, omissions or changes in product specifications.

© 2025 Copyright White International Pty Ltd

TM ® - WARNING: Please be aware that various brands & products depicted within this document are subject to trademark, patent or design registrations. Infringement of any intellectual property contained within this document without express written authority by the appropriate intellectual property holder may result in further legal action to be taken. For any queries regarding use of the contained information please feel free to contact White International Pty Ltd.